

The diagram illustrates a multi-branch enterprise network topology. At the center is the HQ, which includes a core switch (HQ-SW) and a firewall (HQ-FW). The HQ-SW is connected to four branches: FAZ, FMG, BR, and DC. Each branch consists of a local switch and a firewall. The HQ-SW is connected to the branch switches via e0/0 and e0/1 ports. The branch switches are connected to the branch firewalls via e0/0 and e0/1 ports. The branch firewalls are connected to the Internet via e0/0 and e0/1 ports. The Internet is represented by a globe icon. The diagram includes IP addresses for various devices and interfaces, such as 10.0.1.1 for HQ-SW, 192.168.100.205 for HQ-FW, and 10.0.1.10 for HQ-PC1. The diagram also shows a red box highlighting the FAZ branch and a green box highlighting the BR branch.

Change Hostname
FAZVM64-KVM # config system global (global)# set hostname FAZ (global)# end

1 | Page Created by Ahmad Ali E-Mail: ahmadalimsc@gmail.com , WhatsApp: 00966564303717

Configure Route

```
FAZ # config system route
(route)# edit 1
(1)# set device port2
(1)# set gateway 10.0.1.254
(1)# end
```

Testing



```
FAZ # execute ping 10.0.1.254
```



First Time Login:

Once you have configured a port's IP address and network mask, launch a web browser and enter the IP address you configured for the port management interface. The GUI will open with an Evaluation License dialog box. Let's activate a trial license for the VM. Select Free Trial, and click Login with FortiCloud. Use your FortiCloud account credentials to log in, or create a new account. FortiAnalyzer connects to FortiCloud to get the trial license. The system will restart to apply the trial license.

FortiAnalyzer-VM64-KVM

This product requires a valid license. You could log in to FortiCloud to activate your purchased license, or use a free trial license.

ahmadali@sbm.com.sa

.....

☒ Free Trial

☐ Activate License

Login with FortiCloud

OR

Register with FortiCloud

Upload license

Read and **accept** the license agreement.

Free Trial License Agreement



FortiAnalyzer-VM/FortiManager-VM Free Limited License Agreement

TERMS AND CONDITIONS

THESE TERMS AND CONDITIONS APPLY BETWEEN THE ENTITY SET FORTH BELOW (THE "CUSTOMER") AND FORTINET, WHERE BOTH PARTIES CONSENT TO BE BOUND BY THESE TERMS AND CONDITIONS UNDER THIS FREE LIMITED LICENSE AGREEMENT (THE "AGREEMENT"). IF YOU DO NOT AGREE TO THE TERMS, YOU SHOULD NOT ACCEPT THE AGREEMENT AND SHOULD CONTACT LEGAL@FORTINET.COM TO REQUEST CHANGES TO THE AGREEMENT

1) FREE LIMITED LICENSE AGREEMENT.

This Agreement is made for the purpose of testing and evaluating Fortinet's FortiAnalyzer and FortiManager Virtual Machine which have limited features as compared to the full version (hereinafter the "Products") for their potential purchase. Although the Products will have limited features (as detailed below), they will allow Customer to determine if they perform to specifications and expectations.

2) PERMITTED USES AND RESTRICTIONS FOR THE LICENSE.

Fortinet grants Customer a nonexclusive, and nontransferable, limited license to use the Products for testing and evaluation (either by Customer or a third party evaluator). Customers will be provided with 1 limited free trial of the Products with their FortiCare account. The Products will include a maximum of 1 GB/day logs, 3 devices, 2 ADOMs, and do not include services or support, such as FortiCare (support and maintenance) or FortiGuard (subscription services). Customer may use the Products for management and analytics of data generated by other Fortinet products. The trial

☒ I have read and accept the terms in the License Agreement.



Accept

Cancel


If the username and password is correct and reachability to internet, it will connect to FortiCloud will apply the trial license and restart.

Apply License




You have logged in successfully to FortiCloud. The system is restarting to apply the trial license. Please wait for a few moments.

After restart login with your default username admin and the password set first time.




The image shows the login interface for FortiAnalyzer-VM64-KVM. It features a white central panel on a blue background. At the top, the text "FortiAnalyzer-VM64-KVM" is displayed in a large, blue, sans-serif font. Below this, there are two input fields. The first field has a blue icon of a person and the text "admin" inside. The second field has a blue icon of a padlock and three black dots representing a password. Below these fields is a blue button with the word "Login" in white text.

When actions are complete, a green checkmark displays beside them in the wizard, and the wizard no longer displays after you log in to FortiAnalyzer. Click Begin to start the setup process now. Alternately, click Later to postpone the setup tasks.




The image shows the "FortiAnalyzer Setup" wizard. The title "FortiAnalyzer Setup" is at the top in a light gray bar. Below the title, the word "Welcome" is followed by the instruction "Perform the following steps to complete the setup of this FortiAnalyzer." There is a list of four steps, each in a light blue box. Step 1 is "1. Register and SSO with FortiCare" with a green checkmark to its right. Step 2 is "2. Specify Hostname". Step 3 is "3. Change Your Password" with a green checkmark to its right. Step 4 is "4. Upgrade Firmware". At the bottom right of the wizard, there is a blue button labeled "Begin".

When prompted, specify the hostname. In the Hostname box, type a hostname. Click **Next**.



When prompted, change your password. In the New Password box, type the new password. In the Confirm Password box, type the new password again. Click Next.

When prompted, complete the setup by clicking **Finish**.



Setup Complete

The setup of this FortiAnalyzer is now complete. Click "Finish" to exit this dialog.

You are logged in to **FortiAnalyzer**. When you log into the FortiAnalyzer GUI, the following home page of tiles is displayed.

